

Giro,
Dining table 220 x 108
Assembly instructions

kettal

Giro, Dining table 220 x 108


Description

Giro is a collection which can blend into interiors and exteriors due to its tactility and pure lines.

In Giro, we have some variety of shapes, textures and materials (see the difference between the seating items and the coffee and side tables). And still all the items merge harmoniously together to create a warm, tactile and pleasant atmosphere.

cm/inch

74/29,1
70/27,5



220/114,1

108/42,5
35/17,7



35
/17,7

cm/inch



Information

Cleaning Instructions

Use a soft damp cloth, with soap or neutral detergent.
Do not use alcohol or other solvents.

This symbol on the product or its packaging indicates that it must not be treated as household waste. It should, in fact, be handed in at a recognised collection point for recycling electrical and electronic equipment. For more detailed information about the recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.





This product is suitable for indoor and outdoor.

Warning

Bad handling can cause fractures in the furniture.


When lifting or moving the table, always do it from the long sides. If it is caught by the short sides it can be broken.

Elements




Giro, Dining table 220 x 108


1 Place the legs 74 cm apart




2 Place the table top above



3 Rotate the leg until it matches the table top holes




4 Insert screws



3

Adjust the legs height by turning with the screwdriver



4

Lift and move the table always from the long sides. If it is caught by the short sides it can be broken.

